

Pre6, Pre2, eVo2i Custom Machined Remote Control

Display: Toggles Display ON/OFF

Mute: This will switch the analog output mode from Soft to Hard Mute to Un-muted.

VOL+ Ramp up symbol: Increases the volume setting. Used in Program mode to navigate up.

VOL- Ramp down symbol: Decreases the volume setting. Used in Program mode to navigate down.

Right Arrow: This will select the TAPE mode. Used in Program mode to navigate right.

Left Arrow: This will toggle the input selection up in number and wrap around to the first input. Note that the first press of this control will show the active input selection. Used in Program mode to navigate left.

Program: This is used for Standby toggle

Pre/Dac: This button is used as the Enter button on previous remotes

